

TTM-200 brief operation manual

Thank you for purchasing our TTM-200. Please thoroughly read this manual. This manual is a brief version of the operation manual. Please refer to the full version of the operation manual for details. (Payment will incur.)

Cautions

For safety purpose, following symbols are used in this manual.

Warning	The case that a user may receive fatal damage, electric shock, or severe burn injury when the product is incorrectly used
Caution	The case that a user may receive minor damage or the equipment may get damage

Warning	Verify correct wiring before turning on electricity since incorrect wiring may cause an equipment failure or a fire. Modification of this equipment may cause malfunctioning or a fire. Do not add modification on this equipment. If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.
Caution	Wiring: Do not use empty terminals for irrelevant purposes. Operation: Do not use a sharp-pointed tool for operating keys.

- Hand over this operation manual to a person who actually operates the product.
- Do not reprint or duplicate this manual without permission.
- Content of this manual may be subject to modification without prior notice.
- Keep a password in a note if it is set.

Verification of the product

- 1) Verification of the model: Refer the model name printed in the packing box to the order sheet.
- 2) Verification of accessories: Mounting attachment and this manual
- 3) Model table: TTM-200□-□-□-□-□-□-□-□-□-□-□

Model	Casing color	Option	Power supply voltage
4 48x48	Q Black	S CT1 input	100-240V AC50/60Hz
5 96x48	X Gray	T CT2 input	TTM-204 is 10VA
7 72x72		U Event 1 input	Others are 11VA
9 96x96		V Event 2 input	24VAC/DC 50/60Hz
*Not selectable for TTM-204			
Output 1/2			
N None			
R Relay contact (250 VAC, 3A)			
P SSR drive (0-12 VDC)			
A Open collector (24 VDC, 100 mA)			
K Voltage: 0-1 VDC			
J Voltage: 0-5 VDC			
F Voltage: 1-5 VDC			
G Voltage: 0-10 VDC			
I Current: 4-20 mA DC			
H Voltage: 0-10 mVDC			
Output 3-4-5-6-7			
A Open collector (24 VDC, 100 mA)			
R Relay contact (250 VAC, 1A)			
*From output 5 to 7 are not selectable for TTM-204.			
*Output 6 is not selectable for TTM-207.			

Environmental condition

- (1) Service temperature/humidity range: 0-50 °C, 20-90 % RH (no dew condensation)
- (2) Storage temperature/humidity range: -20-70 °C (no freezing or dew condensation), 5-95 % RH (no dew condensation)
- (3) Equipment environment: 1) No corrosive gases, dust, and oil
- 2) As far away as possible from an electric noise source, and little effect from electromagnetic field
- 3) As few as possible with mechanical vibrations or impacts
- 4) No direct sunlight
- 5) Installation(overvoltage) category II /Pollution Degree 2
- 6) Indoor use / Altitude up to 2000m
- 7) Mains supply voltage fluctuations not to exceed ± 10 percent of the nominal voltage

Prior to control operation

- Non-volatile memory is used for storing settings, which stays in the storage even when the power is cut.
- Input form can be switched (Thermocouple, temperature measuring resistor, voltage, and current).
- Match the selected input form with input setting on the product.
- PID control and ON/OFF control are possible. Advantage/disadvantage of them are as follows.
- Select the control in consideration of the advantage / disadvantage.
- * A self-tuning function is equipped on this product so that constants for PID are automatically calculated and reflected to the control at start of control operation or change of SV.

	PID control	ON/OFF control
Advantage	Better control result than ON/OFF control	Longer service life than that of PID control
Disadvantage	Short service life of the relays due to frequent on/off of output	Larger temperature fluctuation than that of PID control




Webpage : <http://www.toho-inc.com>
E-mail : overseas@toho-inc.co.jp

Head office : 1-13-21 Tanashioda, Sagamihara, Kanagawa 229-1125 Japan
TEL : +81-42-777-3316, FAX : +81-42-777-3751

Drawing No. 20-0786-A

Front panel - names and tasks




*Depending on size, some functions may not be available. Refer to model table for details concerning individual functions.


OUT1 to OUT7	Output 1 to 7 monitor (It appears when output)
RDY	RDY lamp (to light up at READY status)
COM	COM lamp (to flicker during communication)
DI1 to DI4	DI 1 to 4 monitor (It appears when DI 1 to 7 Operates)
TMR	TMR lamp (to light up during timer operation)
TIME	To light up when setting is for timer
° C/° F	To light up when setting is for temperature
PV	Reading indication, character indication, and timer setting time indication
SV	Setting indication, operation amount indication, and timer remained time indication
MODE	Mode key To be used when screen is switched.
FUNC	Function key To execute set function
Δ	Up key To be used for increasing setting value To be used for switching input setting mode
∇	Down key To be used for decreasing setting value To be used for switching input setting mode

Wiring


● TTM-204




● TTM-205/209



● TTM-207



Dimensions and panel cut




Caution * When mounting in series, pay much attention to interference with terminals on the adjacent equipment.

Model	a	b	c	d	A	B	C	D	L
TTM-204	45 +0.6 -0	45 +0.6 -0	60 (★1)	120	48	48	48	2	55 (Bxn-3) +0.6 -0
TTM-205	92 +0.6 -0	45 +0.6 -0	120	48	96	48	2	65 (Bxn-3) +1 -0	
TTM-207	68 +0.6 -0	68 +0.6 -0	90	72	72	72	2	65 (Bxn-3) +1 -0	
TTM-209	92 +0.6 -0	92 +0.6 -0	120	96	96	96	2	65 (Bxn-3) +1 -0	


★1: When using TTM-204, take careful note of dimensions in column c when using loader cable.

Mounting

● TTM-204



● TTM-205/207/209



*** Attachment removal technique**

For removal, insert a flathead screwdriver in between body and attachment pawl, and rotate the screwdriver to float the pawl.

*Do not use paint thinner or similar chemical to clean with.
Use standard grade alcohol.

Warning * Use specified size (M3 width 6mm or less) crimped terminals (UL Listed) for wiring and crimping machines & tools (UL Listed).

* A conformity wire: copper/AWG18-24/Temperature rating 80°C.

* Tightening torque: 0.5 Nm (5 kgfm, 4.43lb.ftin)

* Wire with care for polarity (+ and -), if applicable.

* For relay contact output, "C: common" and "NO: normal open."

* For output for SSR drive, match the polarity with input of SSR side and connect.



* For CT input, use specified current transformer (CTL-6-P-H).

Caution * Do not touch terminals while supplying electricity to the product in order to prevent electric shock.


Operation flow diagram

Setting item selection screen


(No display for unselected functions)




SET 1: Input 1 setting mode







SET 2: Input 2 setting mode



SET 3: Key function setting mode



SET 4: Control setting mode




● Set change to ON/OFF control from factory shipment initial setting.

Operation Mode display

Press MODE key for 2 seconds → Press ▲ key twice → Press MODE key once → Change "0" to "1" by ▲ key. Press MODE key for two seconds to back to operation Mode.


* ON/OFF control is set in **BANK** 1 of factory shipment initial setting.
* Sensitivity range is 1°C, when ON/OFF control is set.

SET 5




* Setting mode for OUT2 is **SE06**

SET 7 to




* Setting mode for OUT4,5,6 and 7 are **SE08 SE09 SE10 SE11**


SET 12: CT setting mode



SET 13: DI setting mode




SET 14,





* Setting Mode for Timer 2 & 3 are **SE15 SE16**


SET 17:



SET 18: Initial setting mode



SET 19:



SET 20: Bank setting mode

